



NOTES:

1. WALKWAYS SHALL BE INSTALLED TO GRADES AND ALIGNMENT SHOWN ON DESIGN DRAWINGS. CROSSFALL 2% UNLESS OTHERWISE SPECIFIED.
2. REMOVE ALL ORGANIC MATERIALS PRIOR TO INSTALLATION OF GRANULAR BASE. FILL DEPRESSIONS BELOW GRANULAR BASE WITH 75 mm MINUS PIT RUN GRAVEL.
3. WIRE MESH REINFORCING, 150mm X 150mm, 10 /10 GUAGE, TO BE SPECIFIED IN FILL AREAS OVER 300mm DEEP.
4. WALKWAY TO BE 50mm ABOVE NATURAL GRADE WHERE PRACTICAL.
5. FOR WALKWAYS OVER 50m IN LENGHT OR OVER 8 % GRADE, USE INVERT GUTTER AND CATCH BASINS TO MMCD C10.